

# White Bear Theatre

## Key Tech Equipment List

### **Lighting**

Jester ml24 Desk

(note - when programming, if you override a lighting cue the screen will ask you to confirm the override. If you press 'No', it will still override the cue, so extra care is needed to ensure the correct cue numbers are being programmed.)

- 4x Source 4 Profiles (good for general washes)
- 3x ETC Colour Source 4 Parcans LED (colour changing)
- 3x Lexander Fireball Pars LED (colour changing)
- 12x Par 16 Birdies (good for isolated lighting)
- 4x U'king Stage Light 180W RGBW Par Can (colour changing)
- 4x Alpha Packs only 3 have bracket on which to hang in the rig.

If any further lights are hired or brought in we ask that they be LED or low wattage where possible.

#### <u>Sound</u>

- Yamaha MG12XU
- 2 Crown XLS 1002 Amps
- 4 JBL Control Speakers (moveable)
- multicore sound cable runs from the tech box and can go onstage to run onstage microphones through the sound system.

We do not have an in house laptop so companies will need to bring in a device through which to cue and play sound files.

#### **Rigging**

The rig is unistruts which uses zebedees (these things) (these require m10 size bolts, which the venue has).

Two unistruts are on stage, and two overhead of each seating bank.

Six vertical standing lighting scaff poles (which can be screwed into the raised staging. Screwing in to the floor is the only way to secure them, just using stage weights won't do). Companies need to supply their own clamps to attach lights to these. The heights of the poles are:

#### x1 120cm

x1 150cm x4 260cm

The venue also has x2 in house stage weights.

#### House Lights

There are house lights in the venue over each seating bank, which do not run off the desk, but via a switch on the wall of the tech box these can be faded on or off.

The lampshades can be removed as needed if they end up obstructing the rigged lights.

Other Generic Info

The emergency exit door that goes out the back of the dressing room is alarmed, so should <u>NOT</u> be opened unless absolutely needed

The first aid kit is located within the tech box